

Keyboard Shortcuts - As the Recreated ZX Spectrum's Rubber Keyboard has only 40 keys, a few of the keys - notably the 'CAPS SHIFT' and 'SYMBOL SHIFT' keys - are reserved in its 'QWERTY Mode' to provide access to the additional keyboard functionality not anticipated by the designers of the original Sinclair ZX Spectrum.

CAPS SHIFT + **SYMBOL SHIFT** + **Z** = Switch to Mac/iOS keyboard setting
X = Switch to Windows keyboard setting
V = Switch to Android keyboard setting

CAPS SHIFT + **1** = Escape
2 = Caps Lock
5 = Cursor Left
6 = Cursor Down
7 = Cursor Up
8 = Cursor Right
0 = Backspace
Space = Break

CAPS SHIFT + **SYMBOL SHIFT** + **I** = Insert
0 = Delete
H = Home
E = End
U = Page Up
D = Page Down
T = Tab
P = Print Screen

CAPS SHIFT + **SYMBOL SHIFT** + **A** = Windows/Apple key
C = Ctrl
O = Alt
G = Alt Gr
1-9 = F1-F9
Q = F10
W = F11
R = F12